



## ISRI 6800/337 Pro Air Suspension Seat Operators Instructions

**SAFETY WARNING: VEHICLE MUST BE STATIONARY BEFORE SEAT IS ADJUSTED**

### **Three Point Seat Belt**

### **Shock Absorber Adjustment**

Gently push the lever down for a softer suspension, lift lever for a firmer suspension. Adjust to suit road conditions.

### **Backrest Adjustment**

Apply slight pressure to backrest prior to lifting lever. Lift the lever, using body weight move backrest to required position, release lever to lock.

### **Seat Height Adjust**

Gently lift the lever to raise the seat and press the lever to lower the seat.

### **Seat Tilt Adjust**

Gently lift the lever and lean forward/back to adjust seat. Release lever to lock.

### **Horizontal Isolator (where fitted)**

Push the lever to the right for isolator function to operate, push the lever to the left to lock the Isolator.

### **Air Suspension**

The air suspension automatically sets to the operators weight being between 50 & 130Kg.

### **Air Lumbar Support**

Two lumbar chambers, Lower (LL) & upper (UL) plus air adjustable side bolsters (SB). Press the + to increase and – to decrease. Adjust to give the lumbar region of your back the desired support.



### **Air Dump Valve**

Gently press the lever down once seated, before exiting lift the lever up. This improves entry & exit clearance.

### **Seat Cushion Adjustment**

Gently lift the lever and push hips forward/backwards. Release to lock.

### **Slide Adjust**

Lift slide handle and slide seat back/forward to required position. Release to lock.

For further information contact ISRI Seats Ph. 02 9756 6199

[www.isri.com.au](http://www.isri.com.au)